MIDI Controller list

Nord Stage 2 Parameter	MIDI CC #
Organ Preset II	3
Organ Swell	4
Organ Drawbar 1	9
Organ Drawbar 2	14
Organ Drawbar 3	15
Organ Drawbar 4	16
Organ Drawbar 5	17
Organ Drawbar 6	18
Organ Drawbar 7	19
Organ Drawbar 8	20
Organ Drawbar 9	21
Organ Percussion Enable	22
Organ Model	23
Organ Vibrato Type	24
Organ Vibrato Enable	25
Organ Percussion Harmonic	26
Organ Percussion Speed	27
Organ Percussion Level	28
Organ Octave Shift	99
Organ Level	100
Organ Enable	101
Piano Type	8
Piano Model	29
Piano Slot Detune	5
Clav EQ 1	30
Clav EQ 2	31
Clav Model/Type	65
Piano Dynamics	33
Piano Acoustic	98
Piano Octave Shift	105
Piano Level	106
Piano Enable	107
Piano Pedal Noise	108
Synth Octave Shift	111
Synth Level	112
Synth Enable	113
Synth Glide Rate	34
Synth Arp On/Off	109
Synth Arp Mst Clk	12
Synth Arp Rate	102
Synth Arp Pattern	103
Synth Arp Range	104
Synth Voice Mode	36
Synth Unison	37
Synth Vibrato Mode	38
Synth Mod Envelope Attack	39
Synth Mod Envelope Decay	40
Synth Mod Envelope Mode	41
Synth Mod Envelope Velocity	42

Nord Stage 2 Parameter	MIDI CC #
Synth LFO Rate	115
Synth LFO Waveform	116
LFO Master Clk	13
Synth Oscillator Mode	43
Synth Waveform Select	44 (0-127)
Synth Oscillator Shape	45
Synth Oscillator Shape Mod	46
Synth Filter Frequency	48
Synth Filter Resonance	49
Synth Filter Vel/Env Mod	2
Synth Filter LFO Mod	51
Synth Filter KBT (Keyb. track)	52
Synth Filter Type	53
Synth Amp Envelope Attack	54
Synth Amp Envelope Decay	55
Synth Amp Envelope Mode	56
Synth Amp Envelope Velocity	57
Effect 1 Type	60
Effect 1 Source	61
Effect 1 Amount	62
Effect 1 Rate	63
Effect 1 Enable	69
Effect 1 Mst Clk	117
Effect 2 Type	70
Effect 2 Source	71
Effect 2 Amount	72
Effect 2 Rate	73
Effect 2 Enable	74
Effect 2 Mst Clk	118
Delay Destination	75
Delay Amount	76
Delay Rate	77
Delay Feedback	78
Delay Ping Pong on/off	79
Delay Enable	80
Delay Mst Clk	119
AmpSim Type	81
AmpSim Destination	90
AmpSim Drive	83
AmpSim Bass EQ	84
AmpSim Mid amount EQ	85
AmpSim Mid Range	6
AmpSim Treble EQ	86
AmpSim Enable	87
Rotor Destination	88
Rotor Drive	89
Rotor Speed	82
Rotor Stop	91
Rotor Enable	92
Compressor Amount	93

Nord Stage 2 Parameter	MIDI CC #
Compressor Enable	94
Reverb Amount	95
Reverb Size	96
Reverb Enable	97
Slot Focus	68
Pedal Sustain	64
Pedal Latch	66
Pedal Soft	67
Organ Swell Pedal	4
Ctrl Pedal	11
Rotor Speed Pedal	82
KB Gate Pedal	114
Master Level (if Swell Type is set to Volume in System Menu)	7

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel		1 - 16	1 - 16	
Default Channel		1 - 16	1 - 16	
Mode	Default	Mode 3	Mode 3	
	Message	X	X	
	Altered			
Note		0-127	0-127	
Number	True Voice			
Velocity	Note ON	O, v= 1 - 127	O, v= 1 - 127	
	Note Off	O, v= 1 - 127	O, v= 1 - 127	
After	Key's	X	X	
Touch	Channel	O	O	
Pitch Bender		O	O	
Control Change		O	O	
Program Change		O, 0-127	O, 0-127	
True#				
System Exclusive		O	O	
System	Song Pos	X	X	
Common	Song Sel	X	X	
	Tune	X	X	
System	Clock	X	O	
Realtime	Commands	X	X	
Aux	Local on/off	X	X	
Message	All notes off	X	X	
	Active Sense	X	X	
	Reset	X	X	
Number	True Voice			

Mode 1: Omni On, Poly - Mode 2: Omni O, Mono - Mode 3: Omni Off, Poly - Mode 4: Omni Off, Mono - O = Yes - X = No

Model: Nord Stage 2 OS v1.x Date: 2011-02-01